



**Ersatzteile zu:**

**Spare-parts to:**

**BALSO**

Pos.	Gegenstand	Item	Code
1	Grundplatte verleimt	Base plate	46
2	Pressplatte	Pressure plate	34
3	Anschlagplatte	Stop plate	17
4	Distanzbüchse	Bushing	16
5	Flügelmutter M6	Winged nut M6	10
6	Druckfeder 18 x 5,3 x	Pressure spring 18 x 5,3 x 0,6	5
7	Sprengring	Spacer	5
8	Senk-Schr. m. Kr.Schl. M5 x 1	Screw M5 x 16	5
9	Flachkopfschraube M3 x 6	Screw M3 x 6	5
10	Stiftschraube M6 x 4	Threaded pin M6 x 45	20